Rain chain installation



① Mark the diameter of the downspout on the hook. The coating on the hook prevents electrochemical corrosion with the chain. Do not peel it off.



② Bend the hook so that it is parallel to the chain.



③ Prepare to hang the first chain by attaching stainless steel wire to it.



4 Hang it as close to the spout as possible so that rain water does not splatter. It would be even better to crimp the downspout so that it tapers in.



⑤ Attach the remaining chains a few at a time.



⑥ When removing the connecting wire, remove one side at a time. Likewise, when attaching, screw in each side until it clicks in place.



⑦ Connect all of the units. The connecting wire can fall into the holes, so lift it up to the correct place.



® Make a ring of stainless steel wire on the back of the decorative weight.



Make a ring also on a somewhat large rock that will serve as a weight.



① After hanging the whole chain, connect the Decorative weight and the rock while checking to make sure that it is not too tight.



① Set the rock on the drain.



① Hide the rock with small stones.

* 9 feet is the standard length of our rain chain. The longer the chain, the more weight it will have. Please fortify the connecting area on the gutter as needed, considering factors such as high wind and freezing.